

Connect to an Endian firewall through the serial console

Requirements:


- 1. You need a serial nullmodem cable
- 2. a workstation with serial interface
- 3. a terminal program

Connect the serial nullmodem cable to the console port of your Endian Firewall and the other end to your workstations serial port (COM1).

Use a terminal program (HyperTerminal, PuTTY for Windows, etc.) in order to connect to the Firewall. The necessary parameters are:

- 38400 baud
- 8 bit
- No parity bit
- 1 stop bit

After successful connect, if the firewall is up and running, you should find a menu.







Revision

Revision History

Revision Level	Date	Description
1.0	07/02/2011	Creation of document

Document build number: 6

Note concerning the warranty and the rights of ownership:

The information contained in this document is subject to modification without notice. Check http://wiki.ewon.biz for the latest documents releases.

The vendor and the authors of this manual are not liable for the errors it may contain, nor for their eventual consequences.

No liability or warranty, explicit or implicit, is made concerning the quality, the accuracy and the correctness of the information contained in this document. In no case the manufacturer's responsibility could be called for direct, indirect, accidental or other damage occurring from any defect of the product of errors coming from this document.

The product names are mentioned in this manual for information purposes only. The trade marks and the product names or marks contained in this document are the property of their respective owners.

This document contains materials protected by the International Copyright Laws. All reproduction rights are reserved. No part of this handbook can be reproduced, transmitted or copied in any way without written consent from the manufacturer and/or the authors of this handbook.

eWON sa, Member of ACT'L Group